

Item Number	Quantity	Part Number	Part Name
2	2	3069	3069-TP FRONT FLIP LOCK KNOB
3	1	721	721-LADYBUG MICRO LOCK PLATE
4	2	637	637-LOCK KNOB 6479k38 (3136)
5	1	715	715-LADYBUG MICRO TOP PLATE
11	2	3300	3300-CUPWASHER
14	1	514	514-TAG PRO MICRO SCREEN HOLDER TRAY
15	3	3168	3168-.312 x 2 G8 CS
16	1	504	504-LADYBUG MICRO FRONT SCRN HLDR
17	1	714	714-LADYBUG MICRO BOTTOM PLATE
18	1	622	622- TP FRONT FLIP STUD
20	3	620	620-MICRO ADJUST KNOB
23	2	3158	3158 LOCK KNOB D820

